


UA-37

Sport Wireless Headset

User Manual



CONTENTS

Product Specifications	4
Components	4
Product Diagram	5
Charging Headset	6
Pairing Your Headset with a Bluetooth® device	7
Using Your Headset	8
Troubleshooting	9

Product Specifications

Weight: 15g

Battery Capacity: 60mAh

Wireless Range: Up to 10 meters

Bluetooth version: v4.2

Frequency Response: 20Hz-20KHz

Charging Voltage:DC 5V

Input port: Micro USB

Music Playtime: up to 4 hrs*-Depends on individual use.

Standby Time: up to 150 hrs*


Charging Time: Approx. 1.5hrs*

Components

Thank you for choosing the iXchange Endurance UA-37. We hope you enjoy it! Inside the package, you should find:

- 1 Endurance Bluetooth Earbuds
- 1 Pairs Noise Insulation Earplugs
- 3 Pairs Replacement Earplugs
- 1 Micro USB Charging Cable
- 1 User manual
- 3 Replacement Ear Hooks
- 1 Carrying Case

Product Diagram



Charging Device

Before using your headphone for the first time, please insert the charger into the power source and connect the other end to micro USB charging socket of headset to charge the battery fully.

- Use only the supplied cable for charging
- To extend the battery life, re-charging the battery every 6 months.
- Charging indication will be delayed in a few seconds if the headphone has not been used for a long period of time.

Pairing Your Headset With a Bluetooth® Device

1. Turn on the Bluetooth function in the device.
2. Place the headset and the device where they are visible, within arm's length from each other.
3. Ensure the headset is OFF.
4. To activate the pairing mode of headset, press and hold the MFB until the status indicator flashes blue and red alternately.
5. Search the headset on phone, select 'UA-37' .
6. When the pairing is complete, the status indicator will flash blue.

Using Your Headset

Function	Button	Audio (Speaker)	Status Indicator
Power On	Press and hold the MFB	Power On	Blue LED Is On
Power Off	Press and hold the MFB	Power Off	Red LED Is On
Play / Pause Music	Press the MFB Once	-	Blue LED Flashes in every 3 seconds
Next Song.	Press the "+"	-	-
Previous Song.	Press the "-"	-	-
Adjust Volume	Press the Volume +/- once to increase or decrease	-	-
Incoming/ End Call	Press the MFB Once	-	-
Pairing Your Earbuds With Two Bluetooth (Multi-Point)	-	Second Device Connected	-

Troubleshooting

I cannot pair with my mobile phone

- Ensure your earbuds is power on and fully charged
- Ensure the Bluetooth setting is activated on your phone
- Ensure the earbuds is at pairing mode (flashes blue and red alternately)
- Ensure the earbuds is not out of range of your phone

If the above steps do not solve the problem, please turn off the headbuds and recharge the earbuds, and then try again.

I cannot hear the sound in my earbuds

- Ensure your earbuds is power on and fully charged
- Ensure your earbuds is paired and connected with your phone
- Ensure the volume level is high enough

I cannot turn off the earbuds

Please press and hold the OFF a longer time, otherwise, please recharge the earbuds for 2-3 seconds then disconnect the charger, the earbuds now turns off.

I cannot turn on the earbuds

Ensure your earbuds is power on and fully charged, otherwise, please charge the earbuds for 1.5 hours, and then turn on again.



Made in China